




M SERIES









Modbus


Ethernet/IP

CANopen

Modbus

M-SERIES LINE UP

M



M

|



>



>



>



>



>




>



100

[illegible]



M-SERIES CONTROLLER


M

|







M-SERIES PLC DIMENSION DRAWING

M







M-SERIES CONTROLLER

						
		Byt	Byt	Byt	Byt	
	)			Byte		
				ST	C++	
RT						
					+	
						+
Gc						
USB				U	Ty e C	
				±		
					RT	
		ps)				
	RS232				RT	
		ps)				
C						
Ether et	T				T	e EtherNet
	Socket					TCP P
Ether e						Byt
)						

M-SERIES CONTROLLER

M


																	
		. Byt				. Byt				Byt				. Byt			
	)	Byte															
		ST C++															
	EtherCA													8			
RT						RTC											
Gc																	
USB																	
	RS485					R											
	RS232					R											
C																	
Ether et	T					CP+S et				CP+S e EtherNet P							
	Socket					TCP P				TCP P							
Ether e P)								8				Byt					
EtherCAT																	
	支持协	议	EtherCAT														

M-SERIES LINE UP



M





M-SERIES APOLEGAMY



			
	NPN PNP A > A < A C C		

[illegible][illegible]





M-SERIES UNIT LINE UP

M

M-SERIES UNIT



EtherCAT



2

B
R
T
J
N
E
S

F
F
F
F




F
F
F
F
F
F
F





C
T
NT
NT
NT
NT
NT
NT

t

F

[illegible]32

					
		8		8	
		8		8	
		NPN		PNP	

M-SERIES

UNIT DIMENSION DRAWING

M



M

HCM100-14MR-A		R	R	USB		√	
HCM100-14MT3-A		R	R	USB		√	
HCM100-20MR-A		R	R	USB		√	
HCM100-20MT4-A		R	R	USB		√	
HCM100-30MR-A		R	R	USB		√	
HCM100-30MT6-A		R	R	USB		√	
HCM100-40MR-A		R	R	USB		√	
HCM100-40MT6-A		R	R	USB		√	
HCM100-48MR-A		R	R	USB		√	
HCM100-48MT6-A		R	R	USB		√	
HCM100-60MR-A		R	R	USB		√	
HCM100-60MT6-A		R	R	USB		√	
HCM211-20MR-A		EtherNe		R	USB	√	
HCM211-20MT4-A		EtherNe		R	USB	√	
HCM211-32MR-A		EtherNe		R	USB	√	
HCM211-32MT6-A		EtherNe		R	USB	√	
HCM211-42MR-A		EtherNe		R	USB	√	
HCM211-42MT8-A		EtherNe		R	USB	√	
HCM211-60MR-A		EtherNe		R	USB	√	
HCM211-60MT10-A		EtherNe		R	USB	√	
HCM212-32MT4-A		EtherCA		EtherNe		R	USB
HCM212-60MT8-A		EtherCA		EtherNe		R	USB
HCM301-16MT4-D		R	R			√	
HCM302-16MT4-D		R	R			√	
HCM310-16MT4-D		EtherNe		R	R	√	
HCM311-16MT4-D		EtherNe		R	R	√	
HCM312-32MT6-D		EtherNe		R		√	√
HCM500S-16MT4-D		EtherCA		R	R	√	
HCM501S-16MT4-D		EtherCA		R	R	√	
HCM511S-32MT4-D		EtherCA		EtherNe		R	√
HCM511-32MT4-D		EtherCA		EtherNe		R	√
HCM512-32MT4-D		EtherCA		EtherNe		R	√
HCM513-32MT4-D		EtherCA		EtherNe		R	√
HCM514-32MT4-D		EtherCA		EtherNe		R	√

M

HCMXB-C	-100-BD		
HCMXB-2RS232-100-BD		R	
HCMXB-2RS485-100-BD		R	
HCMXB-ID04-100-BD			
HCMXB	-100-BD		
HCMXB	-100-B	P	
HCMXB-MA03-100-BD			

M

HCMXB-2RS232-200-BD		R	
HCMXB-2RS485-200-BD		R	
HCMXB-ID04-200-BD			
HCMXB-D			
HCMXB-P			
HCMXB-MA03-200-BD			
HCMXB-CA-BD	M3124		
HCMXB-2RS232-BD		R	
HCMXB-2RS485-BD		R	
HCMXB-RTC-BD			
HCMXB-ID04-BD			
HCMXB-D			
HCMXB-P			
HCMXB-MA03-BD			
HCMXB-AB-500-BD	4		
HCMXB-2AB-500-BD			

M

HCMX-EC01-D	EtherCAT									√						
HCMX-TC04-D										√						
HCMX-PT04-D	NT	T	T	T	C	T	T	T		√						
HCMXE-MD16-D	EtherCAT	O	8	8							√					
HCMXC-MD16-D	CA	e	O	8	8							√				
HCMXP-MD16-D		O	8	8							√					
HCMX-ID08-D	8		NPN	PNP							√					
HCMX-ID16-D			NPN	PNP						√	√					
HCMX-ID32-D			NPN	PNP							√					
HCMX	8										√					
HCMX	8		NPN									√				
HCMX	8		PNP								-	√				
HCMX			NPN								√	√				
HCMX			PNP								√	√				
HCMX			NPN									√				
HCMX			PNP									√				
HCMX-MD16-D	8		NPN	PNP	8		NPN				√	√				
HCMX	8		NPN	PNP	8		PNP				√	√				
HCMX-MD32-D			NPN	PNP						NPN		√				
HCMX			NPN	PNP						PNP		√				
HCMX-AD04-D									A	A	A	A	A	√	√	
HCMX-AD04S-D									A	A	A	A	A	√	√	
HCMX-DA04-D									A	A	A				√	√
HCMX-DA04S-D									A	A	A				√	√

M

SysCtrl Studio									